







Návod pro instalaci  
**LKV8360, LKV9360**




A (mm)	B (mm)	C (mm)	D (mm)
641.5	1210	1937	1939-1942




A


1




3







2







4














**B**











**b**

